

Power

Turn on/off a selected device

STB, TV, DVD, AUX

Use one remote to control multiple devices

Record

Record a program

Rew / FF / Stop / Pause / Play / Replay / Fwd

In STB mode, these control the program or DVR functions

Menu

Displays the menu

Arrows and OK

Navigate and select onscreen choices

Arrow Left

While watching a program, access search and search history

Volume +/-

Raise or lower the volume

Guide

Opens the interactive program guide

Mute

In TV mode, turns the sound on/off

Delete

Change orientation to zoom or fit to frame



Recorded TV

Access DVR recordings, view future recordings, view series recording rules, and view/restore deleted recordings

Arrow Right

While watching a program, view program information and scroll through upcoming programs

Info

Displays the current channel and program information. Press again for more detail

A (yellow) / B (green) / C (red)

Access additional features on your STB

Channel +/-

Changes to the next higher or lower channel

Last

Recall the last channel you were watching

Number Keys (0-9)

Directly select a channel or enter options

Enter / Zoom

Turn on/off closed captioning

For more **tutorials**, please scan QR code.

